

6.3

Technology for Real-Time Measurement of Surface and Airborne Beryllium

Tom Kendrick (tkendrick@seabase.com, 505-346-9863)

Nora Tocci (ntocci@seabase.com, 505-346-9825)

David Fugelso (dfugelso@seabase.com, 505-346-9829)

Brian Murphy (bmurphy@seabase.com, 505-346-9851)

Gary Alling (gallings@seabase.com, 505-346-9887)

Science & Engineering Associates, Inc. (SEA)

5651-B Jefferson NE

Albuquerque, NM 87109

Steven Saggese (sjsaggese@sd.seabase.com, 619-294-6982 ext 213)

Ames Grisanti (agrisanti@sd.seabase.com, 619-294-6982 ext 202)

Science & Engineering Associates, Inc. (SEA)

7545 Metropolitan Drive

San Diego, CA 92108

Abstract

The adverse health effects of exposure to airborne beryllium are well known. Personnel exposure to beryllium during clean-up activities or during material processing is a major health

risk within the DOE, DOD, and some private sector industries. Present laboratory-based technologies for evaluating the concentration of airborne and surface beryllium do not provide

the real-time analysis required to effectively protect workers.

In response to this need, Science & Engineering Associates, Inc. (SEA) is developing a multi-function

beryllium monitor based on laser induced breakdown spectroscopy (LIBS). This system will provide the capability to conduct continuous air monitoring for beryllium and the analysis of

swipe or smear samples to detect beryllium contamination on surfaces and equipment.

The

instrumentation is expected to provide measurements of airborne beryllium to levels less than 0.2

$\mu\text{g}/\text{m}^3$, and measurements of surface contamination to less than 0.2 $\mu\text{g}/100\text{ cm}^2$ for swipe

samples. The instrument will operate in a fully automated mode for both the continuous air

monitoring and swipe functions and the system will provide for an alarming function, with the

trigger level set by the operator.

LIBS is an analytical technology that has been used for rapid, in-the-field measurements for a

variety of analytes, with chromium, lead, and beryllium being some of the more common.

To

summarize, a pulsed, high-power infrared laser is focused to a small spot on the sample.

The

very high energy density created at this surface rapidly heats the sample and the surrounding air,

creating plasma. Materials within the plasma are vaporized and the resulting atoms are electronically excited to emit light that is characteristic of the emitting elements. The intensity of

the light emitted by a particular element is proportional to the abundance or concentration of that

element in the mixture. Thus, by spectrally examining the emitted light, the abundance or concentration of a given element may be determined.

Industry Partnerships for Environmental Science and Technology Conference
National Energy Technology Laboratory, Morgantown WV
October 30th – November 1, 2001



Technology for Near Real-Time Measurement of Airborne and Surface Beryllium

Steven Saggese, Ph.D. (PI)

Tom Kendrick (PM)

Science & Engineering Associates, Inc.

Presented by:

Bill Lowry

Science & Engineering Associates, Inc.





Outline



- Benefits of System
- Project Goals
- Scope of Work
- Technical Approach
- System Design
- Sample Data
- Schedule/Cost Status





Benefits



- Provide rapid, in-the-field measurement results for airborne and surface beryllium contamination
- Lower risk of worker exposure to beryllium
- Fully automated operation in the CAM and wipe analysis modes, thereby reducing the labor costs associated with current air sampling schemes





Project Goals




- Functional Performance
 - Provide a CAM function
 - Provide a wipe analysis function
 - Facilitate inclusion of spikes and blanks
 - Provide results traceable to recognized standards
 - Provide alarm capability to D&D personnel
- CAM Measurement Performance
 - Detection limit at or near $0.1 \mu\text{g Be}/\text{m}^3$
 - OSHA peak of $5 \mu\text{g Be}/\text{m}^3$ 15 minute cumulative average
 - Rocky Flats' action limit of $0.2 \mu\text{g Be}/\text{m}^3$
- Wipe Measurement Performance
 - Detection limit of $0.2 \mu\text{g Be}/100 \text{ cm}^2$ or less





Scope of Work





Technical Approach



- Filter-Based Sampling
- Laser-Induced Breakdown Spectroscopy (LIBS)
- Multivariate Data Analysis





Filter-Based Sampling




- Filter-based sampling consistent with standard air monitoring practices
- Filter-based sampling provides more material for evaluation when compared to direct analysis of air, resulting in:
 - Higher SNR
 - Lower Detection Limits
- Multiple modes of operation (CAM & Wipe)
- Allows for spikes and blanks






Laser Induced Breakdown Spectroscopy (LIBS)






Technical Approach – Data Analysis



Ratio



Multivariate





Features of System Design




- Single unit for CAM and swipe analysis
- Windows-based GUI for system operation
- Fully automated operation in CAM and swipe modes
- CAM measurement update every 6 minutes
- 4-hour unattended operation in CAM mode (minimum)
- User-defined alarm levels
- Smooth exterior for easy decontamination
- Uses standard swipes and air filters





System Design



Overview





System Design

LIBS Column




Concept → Design → Hardware





System Design

Filter Holder/ Spark Pattern




Sparkling Pattern
(on metal target)





System Fabrication






System Fabrication




Close-up of Instrument Chamber







System Fabrication, cont



**Loading filter
into holders**



**Loading filter
carousel**



Operating system





Sampling Process (CAM mode)



- System carousel is loaded with clean filters, blanks and spikes
- Carousel is loaded into system and sampling initiated
- Robot loads first filter into CAM port
- Air sample is obtained
- Robot moves filter to LIBS station for analysis
- Robot moves a new filter from the carousel to the CAM port
- Air sampling is initiated
- While the system obtaining another air sample, the robot moves back to the LIBS station and grabs the handle of the sample chamber
- Laser sparking and spectral detection sequence is initiated
- While sparking the robot moves the sample in multiple concentric orbits to spark the entire filter
- The spent filter is removed from chamber and disposed
- Spectral data evaluated with stored calibration algorithms
- Alarm initiated, if required
- Process repeated for entire filter carousel






LIBS Spectra vs. Beryllium Mass



**Beryllium
Peak (313 nm)**




**Beryllium
Peak (332 nm)**





Example LIBS Spectra of Be on Filters






LIBS Data Analysis




- Every spark for a filter is evaluated for data quality and beryllium mass
- Data Quality Acceptance – A primary and secondary data acceptance model is applied to each single-spark spectrum
 - Primary Data Acceptance – The purpose of this evaluation is to detect (and possibly diagnose) instrument malfunctions.
 - Secondary Data Acceptance – This evaluation detects radical changes in the chemical constituents in the sample matrix.
- Beryllium Mass Quantification – High/low concentrations
 - Detector Saturation – Each single-spark spectrum is evaluated for detector saturation and spectra are separated into two classes, those where saturation did not occur and those where it did
 - One of two models (Detector Saturated/Not Saturated) is applied to quantify the mass of Beryllium detected in a single spark.
- The total beryllium mass is the sum of the masses calculated for each of the sparks for a filter






LIBS Data Classification Hierarchy


Data Acceptance





LIBS Data Classification Hierarchy


Beryllium Mass Quantification






RFETS Ambient Dust


LIBS Signal





Scope of Work - Status





Schedule/Cost Status




- Schedule
 - System Design
 - System design completed on schedule
 - System Fabrication
 - All subsystems and components fabricated
 - System integration and testing ongoing
 - System fabrication schedule slightly delayed due to:
 - Laser performance issues (returned to supplier and fixed)
 - Sample chamber design issues (presently being modified)
 - Final system integration to be completed by early November
 - System Calibration
 - Calibration methodology completed
 - Final calibration awaiting final fabricated instrument
 - System Field Demonstration
 - RFETS testing scheduled late-November
 - Wipe and CAM testing
 - System Delivery – On schedule
- Cost – within budget





Schedule





Acknowledgements



- U.S. DOE National Energy Technology Laboratory
 - Mr. Ron Staubly
- U.S. DOE-Rocky Flats Environmental Management Site
 - Mr. Bret Claussen, Mr. Alec Cameron, Mr. Charles Brown
- U.S. DOE Environmental Measurements Laboratory
 - Dr. Adam Hutter
- U.S. DOE Special Technology Laboratory
 - Dr. Stephen Weeks
- Lovelace Respiratory Research Institute
- National Institute for Occupational Health
 - Dr. Mark Hoover

