

LABORATORY RESULTS ON AMMONIA REMOVAL FROM FLY ASH USING AN ACOUSTICALLY ENHANCED FLUIDIZED BED




E. K. Levy and K. B. Lawton
Energy Research Center
Lehigh University

THE PROBLEM

- SCR and SNCR NO_x Control Processes
and
FGC for Improved Electrostatic Precipitator
Operation
- Inject NH₃ or Urea into Boiler
$$\text{NH}_3 + \text{SO}_3 + \text{H}_2\text{O} \rightarrow \text{NH}_4 \text{HSO}_4$$
$$(\text{NH}_4)_2 \text{SO}_4$$
- NH₃ Concentrations on Ash Can Exceed 1000 ppm
- Potential:
 - Health Risk to Workers
 - Groundwater Contamination from Ponded Ash


APPROACH

- **Process Ash Dry**
- **Heat It In Fluidized Bed**
- **Drive Off NH_3**



Sketch of Bubbling Fluidized Bed

FLUIDIZED BED TERMINOLOGY




- U_o - Superficial Gas Velocity
- U_{MB} - Minimum Bubbling Velocity
- $U_o - U_{MB}$ - Excess Gas Velocity

WHY USE FLUIDIZED BED FOR NH_3 REMOVAL?


- **Dry Process**
- **Simple – No Moving Parts**
- **Good Gas- Solids Contacting**
- **Good Tube-To-Bed Heat Transfer**
 - **Low Capital Costs**
 - **Low Operating Costs**
- **Low Fluidization Velocities → Low Air Flow Rates**
 - **Lowers Cost of Off-Gas Treatment for Removing NH_3 and Entrained Ash**

SOME FLY ASHES ARE DIFFICULT TO FLUIDIZE

- **Fine Particles**
- **Van der Waals Forces – Cohesive**
- **Form Large Clusters of Particles in Bed**
- **Get Spouting or Channeling Instead of Regular Bubbling**




USE ACOUSTICS TO IMPROVE FLUIDIZATION




OPTICAL FIBER PROBE

- **8 mm Tube with Two Fibers Located at Inside Wall of Bed 2.5 cm above Distributor**
- **Used to Measure Bubbling Behavior**



Signals from Fiber Optic Probe $[U_0 - U_{MB} = 0.4 \text{ cm/s}]$




FLUIDIZATION PROPERTIES OF DIFFERENT FLY ASHES

Sample Name	LOI %	Without Sound		With Sound (140 dB)	
		U_{mb} cm/s	$\frac{U_o - U_{mb} = 0.4}{f_b \text{ (Hz)}}$	U_{mb} cm/s	$\frac{U_o - U_{mb} = 0.4}{f_b \text{ (Hz)}}$
A	2.7			0.12	16.
B	6.7			0.17	9.7
C	13.	0.40	15.	0.12	19.
D	2.8	0.49	2.5	0.10	21.
E	5.5			0.12	20.
F	5.3			0.12	6.9
G	5.2			0.12	16.
H	7.7			0.12	5.6
I	62.	0.76	*	0.22	*
J	16.	0.31	1.7	0.12	9.9

*The fiber optic probe was unable to measure the bubbles because not enough light was reflected from the particles. This is due to the very high carbon content.

HIGH INTENSITY SOUND

- **Reduces U_{MB}**
- **Improves Consistency of Bubbling**
- **Increases Average Bubble Frequency**





Laboratory Batch Fluidized Bed


BATCH BED EXPERIMENTS

- **Electrical Heating Elements Immersed in Bed**
- **Load in Cold Ash**
- **Fluidize and Heat Ash**
- **Remove Small Samples of Ash as Ash Heats Up**
- **Analyze for NH_3 Content**

FLY ASH - AMMONIA SEPARATION








Ammonia Signal From UV Spectrometer During Ammonium Decomposition Test


CONTINUOUSLY OPERATING SYSTEM


Laboratory System


6" wide x 20 ft long


Up to 500 lb/hr


















ENERGY COSTS

- Ash Fed to Bed at 275 °F
- Heated Electrically → 4 ¢ / kWh
- ~ \$ 2.50 / ton Ash for Energy Costs

OTHER HEATING OPTIONS

- **Burn Natural Gas**
- **Use Economizer Flue Gas**

WHAT'S NEXT?

- **Test Some Other Ash Samples**
- **Test at a Power Plant**
- **Develop Commercial Scale Design**

SPONSORS

- **Cinergy Corporation**
- **Ontario Power Generation**
- **Constellation Energy**
- **First Energy**