

# Increasing the Reliability and Accuracy of Automated, On-Line, Carbon-in-Ash Measurements

Ed Burgher, Tom Hope  
eburgher@rpco.com  
thope@rpco2.com

Rupprecht & Patashnick Co., Inc.  
www.rpco.com



# Topics

---

- Review of R&P On-line CIA Monitor History
- Our Approach to Improving Accuracy and Reliability of an On-line CIA Monitor
- Recent Experience / Field Trials



# **TEOM Series 4100**

## **Automated, On-line CIA Monitor**

---

- Originally Designed and Offered as an On-line LOI monitor (~1988).
- Added CO<sub>2</sub> Monitor to Eliminate Measurement Interference from Oxidation of Non-Carbon Species (sulfur, iron) (~1992)
- Participate in EPRI / Southern Co. Sponsored Evaluation of Automated CIA Monitors (1999)
- Begin Redesign of R&P Monitor based on Findings of EPRI/SC Study, Review of Customer Repair/Support Logs, Marketing Study



# EPRI / Southern Co. CIA Monitor Evaluation Study

## Series 4100 Performance and Findings

---

- **Positives**

- Easiest Installation of All Automated CIA Monitors  
+Doesn't Require Outage.
- Highest Precision & Accuracy, Not Sensitive to Combustion Changes, Coal Type.
- Startup Performance - Best of All Monitors.
- Routine Maintenance - Higher than desired, but easy and not time consuming.
- Constant Sample and Analysis Time - Independent of Load/Cycles.



# EPRI / Southern Co. CIA Monitor Evaluation Study Series 4100 Performance and Findings

---

- **Negatives**

- Low Availability, Low Reliability, High Non-Routine Repairs/Service (related to filter, furnace heating element and sample transfer (silicone) tubing components)
- In addition to above performance related issues, monitor also needed:
  - Replacement of filter cartridge and repair to burnoff heater assembly due to operator error in misaligning burnoff heater during maintenance.
  - Replaced sample probe nozzle to increase sample time.



# TEOM Series 4200 Monitor

## What Is It?

---

- A rugged, automatic monitor for determining the carbon content of fly ash (in percent) at coal-burning facilities.
- The monitor uses first principles to determine the mass and carbon content of collected fly ash.
- This second-generation device incorporates proven sample handling and analysis techniques, and is designed for reliability and minimal maintenance requirements.





# Carbon-in-Ash Test

## Series 4200 Combustion Efficiency Monitor

---

- 1) Collects a fly ash sample isokinetically.
- 2) Transports the fly ash to the Sample Station.
- 3) Weighs the fly ash sample collected on the filter.
- 4) Heats the sample in a high-temp furnace to 800°C.
- 5) Measures the amount of CO<sub>2</sub> generated during the sample oxidation process.
- 6) Calculates the percentage of carbon in the fly ash.
- 7) Reports information to plant personnel and systems.
- 8) Recycles to start another test.



# Operational Considerations

---

- Sample collection and analysis *both* take place at the collection filter—no sample transport.
- Open loop measurement of CO<sub>2</sub> from oxidation provides for reliable carbon determination.
- Analysis process produces very little waste.
- Carbon measurements performed without being influenced by sulfur, iron or boiler additives in the fly ash sample.





# Calculations

---

- Total Mass: 
$$\Delta M = K_0 * \frac{1}{(f_1^2 - f_0^2)}$$

- CO<sub>2</sub> Mass: 
$$CO_2 (kmol) = \frac{vol_{CO_2} (l)}{22.4 \left( \frac{l}{gmol} \right)}$$

- C Mass: 
$$C (gmol) = CO_2 (gmol)$$

$$C (g) = C (gmol) * 12.011 \left( \frac{g}{gmol} \right)$$

- %CIA: 
$$\% CIA = \frac{C (g)}{TM (g)} * 100 \%$$




# Hardware Overview

## Series 4200 Combustion Efficiency Monitor



Series 4200 Enclosure with  
Umbilical and Probe at Top  
(Prototype Unit)



Sample Processing Section of Instrument



# Major System Components


## Series 4200 Combustion Efficiency Monitor

---

- Heated probe and heated umbilical line deliver the sample to the monitor. Probe bundle includes probe for collecting manual sample. Optional second probe permits two point, time-shared sampling.
- Industrial-grade microbalance for fly ash mass measurement.
- Sample analysis system, including furnace and NDIR CO<sub>2</sub> meter.
- Collection and analysis bench positions the mass transducer at different locations.





# TEOM Series 4200 Combustion Efficiency Monitor




# Mass Transducer Positions

## Sample Station




# Heated Probe/Umbilical Line


## Series 4200 Combustion Efficiency Monitor



# Instrument Enclosure




# Sampling / Analysis Unit







# Furnace Assembly



# Instrument Stand



# Series 4200 Combustion Efficiency Monitor

## Improving Accuracy

---

1. Start with a TEOM inertial mass balance.
2. Add sensitive thermal oxidation analysis technique.
3. Add microprocessor control for sample collection, handling and analysis.
4. Develop microprocessor-driven “smart” controls keep inertial mass measurement and thermal oxidation systems operating in their “sweet spots”.



# Series 4200 Combustion Efficiency Monitor

## Improving Accuracy (cont.)

---

5. Add new CO<sub>2</sub> detector with higher resolution and improved calibration stability.
6. Include open path, positive pressure CO<sub>2</sub> flow path design to eliminate measurement errors due to leaks.
7. Use dry, CO<sub>2</sub> free air as carrier gas for CO<sub>2</sub> analysis to improve baseline stability and signal resolution.
8. Use orifice-based Streamline™ flow sensor rather than drift prone mass flow controller.



# Series 4200 Combustion Efficiency Monitor

## Improving Reliability (and Maintainability)

---

- Sample Analysis System Improvements
  1. New furnace design uses reliable, long-life quartz cartridge heating elements and upgraded temperature control.
  2. Positive Pressure CO<sub>2</sub> Pneumatic Path eliminates troubleshooting effort and calibration errors due to leaks.
  3. Orifice-based flow sensor replaces less reliable, higher maintenance mass flow sensor/controller.
  4. Silicone tubing used internal sample line replaced with Teflon tubing.



# Series 4200 Combustion Efficiency Monitor

## Improving Reliability (and Maintainability)

---

- Sample Analysis System Improvements (cont.)
  5. Employ sample transport tubing that is impervious to combustion gases and byproducts.
  6. Upgrade sample line heaters to eliminate unexpected heater failures.
  7. Mass Transducer Cooled to 180°C Rather than Ambient Temp. to Reduce Thermal Stress on Filter Cartridge.



# Series 4200 Combustion Efficiency Monitor

## Improving Reliability (and Maintainability)

---

- Sample Analysis System Improvements (cont.)
  8. Sample Processing Bench Assembly Uses Proven Pneumatic, Linear Slide Mechanism Concept From Partisol-Plus Ambient Particulate Monitor (>1000 currently operating).
  9. Use Linear Slide Mechanism to transport sample between analysis stations - motions accomplished using pneumatics; *no* belt- or motor-driven components.
  10. Design goal to eliminate moving parts where at all possible.



# Series 4200 Combustion Efficiency Monitor

## Improving Reliability (and Maintainability)

---

- Electronic System Upgrades
  1. Use microprocessor-based, electronic control, data acquisition and reporting systems based on proven design used in R&P 8400N Ambient Particulate Nitrate monitor.
  2. Incorporate LCD operator interface into electronics module to allow instrument operation, control and data output at monitor location.
  3. Windows™ - based, remote communications / data reporting software eases data reporting and analysis tasks for system operators and managers.






# **Series 4200**


## **Field Trial Results and Data Examples**




## Series 4200 Field Evaluation Study % CIA




## Series 4200 Field Evaluation Study Mass Capture and Isokinetic Flow Rate




## Series 4200 Field Evaluation Study Analysis of Mass Transducer Baseline ( $f_0$ ) Drift



## Series 4200 Field Evaluation Study Analysis of Baseline CO<sub>2</sub>




**Model 4100 Carbon-in-Ash  
E.C. Gaston Station  
07/15 - 07/19/99**




# Carbon-in-Ash Results

## Central Hudson, Danskammer Station



# Results During Change of Coal Type

## Korea Electric Power Corporation







# Summary

## Series 4200 Combustion Efficiency Monitor

- Direct measurement technique generates carbon results independent of coal type.
- High resolution and accuracy ( $\leq \pm 0.5\%$  CIA).
- Isokinetic particulate matter sampling system.
- System is pneumatically driven—no pumps.
- Allows remote operation from plant control systems.
- Built in self tests and diagnostics that can be viewed remotely or at monitor location.
- Designed for minimal, routine maintenance.

