### SCR Deactivation Mechanisms Related to Alkali and Alkaline Earth Elements

C.L. Senior, T. Linjewile, M. Denison, D. Swensen, D. Shino, M. Bockelie Reaction Engineering International

L. Baxter, C. Bartholonew, W. Hecker, X. Guo, A. Nackos Brigham Young University

> K. Whitty, E. Eddings University of Utah

2003 Conference on Selective Catalytic Reduction (SCR) and Selective Non-Catalytic Reduction (SNCR) for NO<sub>x</sub> Control

> October 29-30, 2003 Pittsburgh, PA







### REI SCR Catalyst Deactivation Program

- DOE- and EPRI-funded program:
  - REI
  - University of Utah (UU)
  - Brigham Young University (BYU)
  - Stan Harding (N.S. Harding Associates)
  - Catalyst manufacturers
- Principal Tasks:
  - Fundamental analysis of SCR catalyst poisoning and regeneration (BYU)
  - Multi-catalyst slipstream reactor to be tested at two utility boilers for six months (REI, UU)
  - SCR deactivation model suitable for CFD code (REI)





### Mechanisms for SCR Catalyst Deactivation

- Fouling (surface deposition)
  - Deposition of ash
  - Sulfation of deposit observed with PRB
- Pore condensation (and/or pore blockage)
- Poisoning
  - Vapor-phase As (as As<sub>2</sub>O<sub>6</sub>) thought to react with active sites in some cases

Literature suggests fouling plays a role in deactivation from both PRB and biomass

Pore condensation could be a factor





### Subtask 1 – Catalyst Deactivation Studies

- Laboratory investigation at BYU using small catalyst samples
- Effects of alkali impurities on reactivity
- Characterization of catalyst (physical and chemical) before and after lab/field testing
  - Adsorption studies in flow reactor
  - Surface analysis (e.g. XPS), TEM/SEM, XRD, FTIR, TPD
  - No chemical analysis of any commercial catalysts.
- Current Status: Literature search completed; NO<sub>x</sub> activity measurements and spectroscopy of catalysts underway at BYU



### Two Primary Analysis Systems


- In situ spectroscopy reactor (ISR)
  - FTIR analyses of SO<sub>2</sub>, NH<sub>3</sub>, and NO<sub>x</sub> adsorption and desorption behaviors:
  - Obtain quantitative Brønsted and Lewis acidities on fresh and exposed surfaces based on spectral signatures
  - Determine surface kinetics and active sites
- Catalyst characterization system (CCS)
  - Obtains quantitative activities/deactivation
  - Focuses on kinetic coefficient and mechanistic information
  - Simulates industrial flows with compositions of: NO, 0.10%;
     NH<sub>3</sub>, 0.1%;
     SO<sub>2</sub>, 0.1%;
     O<sub>2</sub>, 2%;
     H<sub>2</sub>O, 10%;
     and He, 87.7%
  - Custom and commercial catalysts tested as fresh samples and after exposure under both steady and transient conditions






## In-situ FTIR Analysis of Catalyst Sulfation

#### 5% V<sub>2</sub>O<sub>5</sub>/TiO<sub>2</sub> during wet sulfation





### Ammonia Adsorption on Sulfated Catalyst




- After exposure to NH<sub>3</sub>, three new bands:
- Bending vibration of NH<sub>3</sub> chemisorbed on Brønsted acid sites (1433 cm<sup>-1</sup>)
- Stretching vibration of NH<sub>3</sub> adsorbed on both Brønsted (~ 3030 cm<sup>-1</sup>) and Lewis acid (~3350 cm<sup>-1</sup>) sites





### Ammonia Adsorption on Sulfated Catalyst



#### Conclusion:


- Sulfation helps to increase surface acidity, especially Brønsted acidity
- Ammonia adsorbs
   mainly on Brønsted acid
   sites on sulfated
   catalyst surface





### Complimentary Analytical Techniques

#### Percentage increase of N 2 signal



- Mass Spectrometry (MS) of products during in-situ FTIR
  - Surface reaction of NO+NH<sub>3</sub>
  - Effect of catalyst pretreatment
- XPS (surface composition analysis) of catalysts exposed at 380°C





### Complimentary Analytical Techniques


	Wet	Wet	Dry
	sulfated	Sulfated	sulfated
	Sulfur Atom%		
with NH <sub>3</sub>			
adsorption	1.87	0.77	0.15
without NH <sub>3</sub>			
adsorption	0.00	0.00	0.00

- Mass Spectrometry (MS) of products during in-situ FTIR
  - Surface reaction of NO+NH<sub>3</sub>
  - Effect of catalyst pretreatment
- XPS (surface composition analysis) of catalysts exposed at 380°C
  - NH<sub>3</sub> adsorption removes surface sulfate species





### Catalyst Activity Measurement




- Powdered catalyst samples exposed to simulated flue gas:
  - NO, 0.10%; NH<sub>3</sub>, 0.1%; SO<sub>2</sub>,
     0.1%; O<sub>2</sub>, 2%; H<sub>2</sub>O, 10%; and
     He, 87.7%
- NO and NH<sub>3</sub> measurements at inlet and outlet
- Four reactors in parallel multiple catalyst samples evaluated





# Catalyst Activity As A Function of Temperature




INTERNATIONAL

- Fresh BYU catalyst
- Reactivity (NO conversion) calculated from NO and NH<sub>3</sub> measurements



# Catalyst Activity As A Function of Space Velocity (Flow Rate)



INTERNATIONAL

- Fresh BYU catalyst
- Reactivity (NO conversion) calculated from NO and NH<sub>3</sub> measurements



## Status and Preliminary Conclusions: Lab Studies

- In-situ spectroscopy reactor (ISR)
  - Ability to observe adsorption of key species on surface as a function of temperature and gas composition
  - Future work on poisoned and aged catalyst samples
- Catalyst characterization system (CCS)
  - Custom catalysts tested (fresh samples)
  - Future work on poisoned and aged catalyst samples from field testing







### Subtask 2 – Field Testing in Slipstream

- Six catalysts evaluated in parallel
  - Four vendors have supplied catalyst; one "generic" catalyst from BYU
- Monitor catalyst activity by
  - NO<sub>x</sub> measurement
  - Periodic removal of catalyst samples for lab testing at BYU
- First test: AEP Rockport Unit 1
  - Burns PRB-bituminous blend






### Features of Reactor Design

- Multiple catalysts in parallel (plate and honeycomb)
- Catalyst exposed to gas and particulate matter
- Velocity of full-scale SCR
- 1 ½ 3 foot catalyst samples to avoid favoring end effects
- On-line, continuous NO<sub>x</sub> measurement for detailed kinetic information





#### Reactor Schematic



# SCR Reactor Installation at Rockport Plant




Inlet line being installed



Reactor installed across air preheater




### SCR Control System



- Embedded microcontroller
- Ethernet link to local PC for data logging and communication
- Controlled remotely by REI




### Operating Experience



~2700 hours of cumulative flue gas exposure




### **Catalyst Activity**



- Activity
   measured
   using inlet
   and outlet
   NO
- $NH_3/NO$  ratio = 1.1



# Change in Catalyst Activity: April to August



# Status and Preliminary Conclusions: Slipstream Reactor Studies

- 2700 hours of operating experience
- On-line activity measurements made
- 25% of catalyst samples have been pulled for lab analysis
- Plant is currently in an outage, back in November
- Testing will continue for another 3 months



#### Subtask 4 – Deactivation Model

- REI developing SCR reactor model for overall power plant model
- Formulate deactivation sub-model based on laboratory and field testing
- Integrate with REI SCR model

Current Status: Preliminary SCR model implemented









### SCR Model – Approach

- Solve gas transport and surface reactions along length of catalyst
- Surface equations are solved
  - Surface species concentrations of specific sites
  - Steady state assumption
  - Solution dependent on local gas species concentration
- Effectiveness factor to compensate for porous diffusion
- Gas species transport equations
  - Rates from surface equation solution



#### 1D Model - Status



NO reduction and NH<sub>3</sub> slip for two space velocities (181 Nl/h/g and 58.7 Nl/h/g). Filled symbols indicate NO reduction and open symbols indicate ammonia slip concentrations.

- 1D model has been validated against open literature data [Dumesic et al., J.Catal, 1996, 163, 409-417]
- Model includes effectiveness factor for catalyst pore diffusion
- Catalyst deactivation or poisoning to be added

