



# Thin Film Structures and Low Temperature Electrodes for SOFC's



H.U. Anderson, W. Huebner,  
I.Kosacki, Z. Byars and B.  
Gorman

Electronic Materials Applied Research Center  
Ceramic Engineering  
University of Missouri - Rolla  
Rolla, MO 65401

*EPRI / GRI / DOE Fuel Cells Review Meeting  
Chicago, IL*

*August 1999*

# Acknowledgements

- Funding for this Work has been Provided by:
  - DOE under Contract no. (DE-FG26-98FT40487)
  - GRI
  - University of Missouri - Rolla (EMARC)
  - Missouri Dept. of Economic Development
- Special Thanks go to Los Alamos National Laboratory for the use of their JEOL 3000f High Resolution Transmission Electron Microscope

## Advantages of Thin Film Solid Oxide Fuel Cells

---


- Reducing the electrolyte thickness in a SOFC decreases the amount of IR losses in the electrolyte
- Reducing the ohmic losses allows the fuel cell to operate at much lower temperatures
- Benefits from reducing the operating temperature include:
  - Metals can be used at the interconnect
  - Less reaction occurs between cell components, increasing cell lifetimes
  - Greater cost effectiveness during operation
- Using nanocrystalline electrolytes can further reduce IR losses
- A reliable, cost effective, industrial scale thin film processing technique is needed to produce thin film electrolytes

## Thin Film Polymeric Precursor Spin-Coating Technique\*

- Standardized aqueous solutions of cationic salts are mixed in appropriate ratios according to the desired oxide
- Add polymerizable organic
- Condensation polymerization reaction occurs and bonds the cations into the backbone of the polymer
- Polymerization reaction continued over heat until desired viscosity (<100cps) is achieved
- Spin coat polymer precursor on rigid substrate
- Heat substrate with polymer film at 70°C until the film has cured (typically 2 hrs)
- Pyrolize the polymer film at low temperature to yield dense nanocrystalline oxide film
- Repeat depositions until desired oxide film thickness has been reached

*\*U.S. Patent # 5,494,700*

# Polymeric Precursor Spin Coating Technique - YSZ



# EMARC Facilities & Equipment

---

## Analytical

- ◆ X-Ray Diffraction (low and high temperature)
- ◆ DTA / TGA (controlled atmosphere)
- ◆ Dilatometry (controlled atmosphere)
- ◆ Field-emission scanning electron microscopy with EBSP
- ◆ Transmission electron microscopy
- ◆ Energy dispersive X-Ray microanalysis
- ◆ Atomic force microscopy
- ◆ Scanning auger spectroscopy / ESCA
- ◆ SIMS

## Electrical

- ◆ 2- and 4-point DC conductivity
- ◆ AC impedance spectroscopy
- ◆ Thermoelectric power

# EMARC Facilities & Equipment

---

## Processing

- ◆ High temperature (1900°C) controlled-atm furnaces
- ◆ CVD / EVD / PVD with Pt deposition
- ◆ Powder processing - Pechini, glycine-nitrate, sol-gel
- ◆ Powder Characterization:
  - BET / Surface Area
  - Particle Size Distribution
  - Viscosity / Rheology

## Magnetic / Optical

- ◆ RAMAN Spectroscopy
- ◆ Mössbauer Spectroscopy
- ◆ FTIR
- ◆ Nuclear Magnetic Resonance

## EMARC Facilities & Equipment

---



Class 1000 Clean Room

- EMARC has recently invested  $\approx$ \$200,000 in a class 1000 clean room.
- Equipment in EMARC clean rooms
  - Enclosed Tape Caster
  - Spin Coater
  - Screen Printer
  - Lamination Press




Enclosed glass bed tape  
caster with hepafilters




Spin Coater



# Electrode Testing System




Electrode Testing System



Fuel Cell


- EMARC has the ability to test different electrode materials under fuel cell conditions.
- A reference electrode is buried inside the electrolyte.
- This allows the anode and cathode overpotentials to be separated.



## Thin Film SOFC Testing System




# Thin Film SOFC Testing System






## YSZ Thin Film Electrolytes

70nm thick electrolytes on porous NiO/YSZ  
produced by a thin film transfer technique and  
annealed at 1000°C



## YSZ Thin Film Electrolytes



0.5μm thick electrolytes on porous NiO/YSZ  
using a thin film transfer technique and  
annealed at 1000°C






## Grain Growth Kinetics

**Bright Field TEM micrographs of an unsupported YSZ thin film annealed at A) 600°C and B) 800°C**




## Grain Growth Kinetics

**High resolution TEM micrograph and SA diffraction pattern of an unsupported YSZ thin film annealed at 400°C.  $d_g = 5\text{nm}$**




# Thin Film Grain Growth

- Unsupported YSZ thin films examined in the TEM after annealing at several temperatures and times
- Grain growth follows a  $\text{time}^{1/2}$  dependence initially and stabilizes with extended time
- Grain sizes are in the nanocrystalline regime after heat treatments to  $800^{\circ}\text{C}$




# Optical Absorption Measurements on Nanocrystalline YSZ Showed the Band Gap Increased with Decreasing Grain Size •







# Quantum Confinement in Nanocrystalline YSZ



# Nanocrystalline YSZ Exhibits an Enhanced Ionic Conductivity: $pO_2$ dependency



# Nanocrystalline YSZ Exhibits an Enhanced Ionic Conductivity: Impedance Spectroscopy



## Nanocrystalline YSZ Conductivity Results


---

- ◆ Impedance spectroscopy measurements were performed on YSZ thin films with different annealing temperatures
- ◆ As the grain size of nanocrystalline thin films decreases, the electrical conductivity increases
- ◆ Due to a higher grain boundary area, the mobility of vacancies increases
- ◆ Specific grain boundary conductivity increases due to the segregation of impurities

## Nanocrystalline YSZ:


- ◆ Optical absorption measurements were used to determine the band gap in YSZ thin films
- ◆ As the grain size decreases, the band gap increases, which decreases the electronic conductivity
- ◆ Enhanced conductivity in nanocrystalline YSZ thin films is strictly ionic

## Influence of Volume % Nickel on the Anodic Overpotential



Initial  $\eta$ -j relations of Ni-YSZ cermet sintered at 1400°C.

## Influence of Volume % Nickel on the Anodic Overpotential: Initial and 24h Results



$\eta$ -j results, initially and  
after 24 h, for Ni-YSZ  
cermets sintered at 1400°C.

## Summary of Anode Studies

---

- Compositions studied ranged from 40-55 volume % Ni
- Oxide powder mixtures were calcined at 900°C, sintered on the electrolyte at 1400°C, and then reduced in situ.
- The 40 and 45 vol% Ni samples show similar behavior, 220 and 200 mV at 1000mA/cm<sup>2</sup> initially, rising to  $\approx 270$  mV/cm<sup>2</sup> after 24 hours.
- The 50 and 55 vol% samples showed much higher overpotentials, both initially and after 24 hours.
- The low vol% Ni samples have lower overpotentials due to the larger YSZ content in the cermet. The increased YSZ reduces the sintering of the nickel particles.



# Summary

- EMARC has developed a technique for processing dense, nanocrystalline thin films.
- Research has focused on the electrical and microstructural characterization of solid oxide fuel cell electrolyte and electrode materials.
- Utilizing a transfer technique, fuel cells with thin film electrolytes were produced and tested.

## Future Work

- Measure current and voltage performance with different electrolyte thicknesses at low temperatures.
- Develop a measuring protocol for separating overpotentials of the anode and cathode for thin film fuel cells.
- Utilize mixed conductors as electrodes.
- Introduction of interfacial layers to prevent reactions.